



- 1a & 1b:** The long longitudinal bands under the headrest and pull them over the back.
The two shorter straps of the seat back through type seat gap and connect with the longitudinal bands.
- 2a & 2b:** Assemble the two side and front bands under the seat and fasten on voltage
- The side airbags must remain free.
 - The **Dino** seat cover fits for the driver and passenger seats
- 3:** An integrated control unit allows you to set two different heat levels and the heating on and off
- heating level 1: For a pleasant warmth (Low)
 - heating level 2: For rapid heating of the seat cover (High)
- 4:** The electrical connection is made via the cigarette lighter (12V)
- Fuse to protect the connector - In case of overload or short circuit
 - The connector integrated LED lights up red when the connection is correct
 - Operating voltage: 12V

Please note that the seat cover is not allowed to be cockling or overlaid. Use per cigarette lighter only one **Dino** seat cover.

Cleaning:

Dino seat covers can easily with a damp cloth or cushion cleaners be cleaned. For this purpose, the **Dino** seat cover must be removed from cigarette lighter.